

Lens Port Cover for Camera Housings (TypeF)

FANTASEA
line

Catalog No. 11187

Instructions for Assembly:

Frame 1

Logo side facing out, secure one side of the port cover to the outer rim of the housing port with your index finger press on it hard. Then pull the opposite side slightly to allow the port cover to reach the far side of the lens port.

Frame 2

Using your thumb and index finger pull the lens port cover of the opposite edge and pull down on the lens port to secure

Frame 3

Lens port cover in place.



Or Instructions for Assembly:

Frame 1

Place the Lens port cover (with logo facing out) on top of the lens port rim with the side edges facing up. Place both hands on the inside of the lens port cover side edges using your thumb and index finger of both hands.

Frame 2

While applying some pressure on the Lens port cover, roll the side edges downward using the thumb and index finger of each hand until secure over the Lens port.

Frame 3

Lens port cover in place.



Please note:

- The lens port cover is very buoyant and will float away if not secured to the housing.
- The Lens port cover should be washed thoroughly with fresh water and then dried after every use.
- Should be stored in dry condition and not in the sun or moist environment.
- It is suggested that you install the lens port cover over the housing port whenever transporting or storing the housing.