

## **Instruction Manual for** **Extension Ring 30/35/40/50/70 with** **Focus knob**

PN# 21230/21235/21240/21250/21270

### **FOREWORD**

Thank you for your purchase of a NAUTICAM product.

At NAUTICAM, we pride ourselves in the ability to recognize the requirements of professional as well as amateur underwater photographers and fulfill them through the innovative designs of our products. We strive to achieve a high level of user-friendliness by allowing stress-free installation and easy operation of all important functions of the camera.

Please read this manual carefully before using the product, this will maximize its performance as well as its lifetime.

### **WARRANTY**

All NAUTICAM Products are warranted against any material and manufacturing defects for two years from the date of purchase for consumer use. This warranty only applies to products purchased from authorized NAUTICAM dealers and does not extend beyond the original retail purchaser.

To return your product for service, please contact your regional authorized service center(s). Please note that this warranty only applies when the product is purchased in the territory where the service center is located.

NAUTICAM does not hold responsibility for damage, of any nature, to any equipment used with and/or placed within our products.

NAUTICAM accepts no liability for any loss of captured images or the inability to capture images even if it is due to the malfunctioning of our products.

Unauthorized modifications and/or repairs of our products will automatically invalidate the warranty.

### **MOUNT ON THE PORT**

Please follow the instructions below to mount the Extension Ring on a port.



1. Confirm that the Extension Ring 30 /70 is unlocked, with the locking lever pointing upwards as shown.



2. Align the "I" mark on the extension ring with the WHITE dot on the port.

Gently push the extension ring towards the port until it cannot go any further.



3. Turn the extension ring clockwise until the white dot on the extension ring aligns with the white dot on the port.



4. Push the locking device inwards. Ensure that the extension ring is securely locked with the port

To unlock, release the locking device and reverse the above procedures.



**Compatibility:**

This extension ring is backwards compatible with other N120 extension rings. A user installable locking tab is pre-installed for this purpose.

Remove the locking tab when using large diameter lenses, such as Canon 11-24mm lens.

**MOUNT THE PORT TO THE HOUSING**



1. Pull the control knob outwards and make sure the control knob is at its most outwards position before mounting/unmounting the port. The knob should be left at this position until it is made sure that the lens and focus gear is properly installed.



2. Engage the gear by pushing in the knob, then turn the knob both ways to check if the lens focuses.

**PRE-CAUTIONS**

- After installation of the port combo, please make sure the o-ring (s) are free from debris and uneven surface issues.
- A water-tight test without the camera inside the housing is highly recommended after the changing of port and O-ring(s).
- Do not use lubricants from other brands with the silicone rubber O-ring on this housing, only use the lubricant provided by NAUTICAM.
- Discontinue use immediately should you notice any leakage.
- Do not open the product in a wet or sandy environment. Protect the interior from moisture and debris in order to prevent malfunction or leakage.
- Defective products should be shipped to our distributors for service, unauthorized disassembling and/or modifications could result in malfunction or leakage.

Remark: Nauticam supports only e-manuals. Please download corresponding product manuals on [Nauticam.com](http://Nauticam.com) website, or contact us for e-manuals.