

Instruction Manual for Bayonet Converter for NA-TG5 / Olympus PT-058/059

PN#83255, #83256

FOREWORD

Thank you for your purchase of a NAUTICAM product.

At NAUTICAM, we pride ourselves in the ability to recognize the requirements of professional as well as amateur underwater photographers and fulfill them through the innovative designs of our products. We strive to achieve a high level of user-friendliness by allowing stress-free installation and easy operation of all important functions of the camera.

Please read this manual carefully before using the product, this will maximize its performance as well as its lifetime.

WARRANTY

All NAUTICAM Products are warranted against any material and manufacturing defects for two years from the date of purchase for consumer use. This warranty only applies to products purchased from authorized NAUTICAM dealers and does not extend beyond the original retail purchaser.

To return your product for service, please contact your regional authorized service center(s). Please note that this warranty only applies when the product is purchased in the territory where the service center is located.

NAUTICAM does not hold responsibility for damage, of any nature, to any equipment used with and/or placed within our products.

NAUTICAM accepts no liability for any loss of captured images or the inability to capture images even if it is due to the malfunctioning of our products.

Unauthorized modifications and/or repairs of our products will automatically invalidate the warranty.





Positioning Block

Hard Cap

Bayonet Converter for Olympus PT-058/059

INSTALL TO NA-TG5 HOUSING



Remove the optical fiber connector from housing, then install the optical fiber connector provided.



Align the 4x positioning blocks on the bayonet converter with the slots on the front of the housing.

```
--- continue on next page ---
```

--- continued from front page ---



Place the locking ring on the bayonet converter, then fasten the converter on the front of the housing with the fastening tool provided.



Remove the Olympus optical fiber connector from housing, then install the optical fiber connector provided.



Align the positioning block on the bayonet converter with the slots on the front of the housing.



Place the locking ring on the bayonet converter, then fasten the converter on the front of the housing with the fastening tool provided.



*Attention: Before installing WWL-C into the housing, pre-install the optical fiber cables as shown in case of using strobes.



Example: WWL-C with bayonet Converter on the NA-TG5 housing.

INSTALL TO OLYMPUS PT-058/059

--- continued from front page ---

SPECIFICATIONS

PN#	Description	Weight
83255	Bayonet Converter for NA-TG5 (to use with WWL-1/WWL-C)	125.5g
83256	Bayonet Converter for Olympus PT- 058/059 (to use with WWL-1/WWL-C)	124g

COMPATIBILITY

Compatible	83203 Wet Wide Lens Compact (WWL-C)
Lenses:	83214 Bayonet Mount Adaptor for SMC/CMC

Remark: Nauticam supports only e-manuals. Please download corresponding product manuals on Nauticam.com website, or contact us for e-manuals.